

TURN ON FIRE PIT

Gas Key is located next to meter on back of column.


- 1) Remove lid from firepit



- 2) Use gas key to turn on gas



- 3) Set time on auto shut off past 20min, make sure red knob (emergency stop) is popped out. Turn knob ¼ to pop out



- 4) Use push button ignition to light



SHUT DOWN FIRE PIT

- 1) Turn off gas with key



- 2) Run timer down to expire. DO NOT SPIN DIAL TO OFF, THIS WILL WEAR DOWN SPRING GEARS – if want to stop early push in emergency stop.



- 3) Place lid on fire pit



- 4) Rehang key on back of column



Emergency shut off, located on timer push in to shut off

This will need to be pulled back out to reignite.

PLEASE KEEP THE FIRE PIT COVERED WHEN NOT IN USE.

If the Ignition button is not clicking to ignite, unscrew button and replace battery.